

1960-64 Galaxie / Fairlane 2 Dr Sedan Door Weatherstripping installation



HELPFUL TIPS

NOTE: It is necessary to use a weather stripping adhesive in order to install door seals. Dennis Carpenter Ford Reproductions recommends and sells 3M brand Weather Stripping Adhesive. Our part # is COAZ-19554-A

BEFORE APPLYING WEATHER STRIPPING

Experience has shown us that taping the door seal into position before any adhesive is applied allows you to check the fit of the seal and to make any door adjustments if necessary.

Apply the adhesive to the door, not the seal. Glue around the door as described in the instructions.

The best (and cleanest) results comes from glueing a 12" to 18" section of the door at a time, applying the weather stripping then taping it into position before continuing onto the next 12" to 18" section.

After the adhesive has had ample time to cure the tape can be removed.



4140 Concord Parkway So., Concord, NC 28027
(704) 786-8139 email: info@dennis-carpenter.com
www.dennis-carpenter.com

INSTALL FRONT DOOR SEALS

1 Remove the old door seals and glue material from the doors. Clean doors thoroughly where the seals are to be adhered. A degreaser/ wax remover solution is recommended.

2 Determine the left and right door seals.

3 Start door seal application by beginning at the upper rear corner of the door window frame (corner A on illustration). Glue and apply door seal along the top and towards the front of the door.

Continue application down the front of the door glass frame. At the bottom of the door glass frame the rubber seal is curved to match the shape of the door at this location.

Continue down the hinge side to the bottom of the door then along the bottom of the door to the rear. Apply the rubber seal around the lower rear corner then up the latch side of door then finishing at upper rear corner (A).

Begin applying
at corner A

