B7A-6420530-PR 1957-58 Ford 2 door Sedan Door Weather Stripping Installation



NOTE: It is necessary to use a weather stripping adhesive to install door seals. Dennis Carpenter Ford Reproductions recommends and sells 3M brand Weather Stripping Adhesive. Our part # is COAZ-19554-A

Experience has shown us that taping the door seal into position before any adhesive is applied allows you to check the fit of the seal and also aides in applying the seal.

Apply the adhesive to the door, not the seal. Glue around the door as described.

The best (and cleanest) results comes from adhering a short section of the door seal at a time by removing the securing tape, applying the glue and positioning the the door seal, reapplying the tape then continuing. After the adhesive has cured the securing tape can be removed.

Remember that new door seals are more resilient to compression and will cause your doors to close tightly.

FORD RESTORATION PARTS DENNIS CARPENTER SINCE 1970

4140 Concord Parkway So., Concord, NC 28027
(704) 786-8139 email: info@dennis-carpenter.com
www.dennis-carpenter.com

TO INSTALL DOOR SEALS

Instructions describe driver's door (left side) seal installation

CAUTION

When adhering the door seals to the doors take care not to stretch the seals. It is important that the molded corners of the seals register into the corresponding corners on the doors.

Make sure that the seals are not twisted before beginning application.

1. Remove the old door seals and residue from the doors. Clean the doors where the seals are to be adhered with a degreaser/wax remover solution.

2. Determine the left and right side door seal. The part number followed by the word LEFT or RIGHT is indicated on the molded corners of the weather stripping.

3. Beginning at the front of the vent window, position the molded corner and glue the door seal along the top of the door to the rear corner of the door. Return to the front of the door and glue the seal down the vent window, through the "dog leg" down to the bottom front corner of the door.

4. From the bottom front corner of the door continue glueing along the bottom to the rear corner then upward to the top rear corner.

5. It is recommended to allow the adhesive to cure for 24 hours before removing the tape that secures the seals to the doors.



